

<b>RELEASE INSTRUCTION (RI)</b> <b>NO RETURN RECEIPT</b>		Document No: <b>DOE-RL-92-36</b>
		Page 1 of 1
		Title: <b>Hanford Site Hoisting and Rigging Manual</b>  Release No.: 9  Date Prepared: August 14, 1998
When Document is no longer needed, please recycle/destroy contents and binder. Sign and date the UDC Unclassified Coversheet and return to UDC, A3-95, indicating "DESTROYED".		If you have any questions about this release contact:  For document control questions, contact: LMSI Document Control - (509) 372-1696. For technical questions, contact: Ray Pope - (509) 376-3223

<p align="center"><b>CONTROLLED COPY INSTRUCTIONS</b></p> <p>1. REMOVE AND/OR INSERT INDICATED SECTIONS INTO DOCUMENT AS SHOWN BELOW.</p> <p>2. UPDATE THE RELEASE RECORD AT THE FRONT OF THE DOCUMENT.</p>
---

SECTION NO. AND TITLE(S)	REMOVE			INSERT		
	PAGES	REV	DATE	PAGES	REV	DATE
Main Table of Contents shows implementation date for the revised sections of Chapters 14 and 18 and the new Chapter 15. NOTE: This is the Table of Contents for the entire manual. It replaces the Table of Contents in the front of the manual.	2-3		06/26/98	2-3		08/31/98
Chapter 14, "Mobile Cranes" Revisions include: (a) Sections 14.4.5.17 and 14.4.6. Reference to Chapter 15 was added. Reference to para 14.4.6 was removed.	10		08/01/97	10		08/31/98
Chapter 15, "Personnel Lifting" This is a new chapter.	N/A		N/A	1-18		08/31/98
Chapter 18, "Hoisting and Rigging in Hostile Environments." Revision includes: (a) Section 18.3.5.1. Revised the RL distribution recipient of Hostile Environment Plans.	4		01/15/93	4		08/31/98

**IMPLEMENTATION NOTICE**